

PARTS LIST

Index No.	Part Number	Description
1	DV559	FRONT PANEL UPPER
2	DV560	INSULATION—FRONT PANEL UPPER
3	DV562	FRONT PANEL LOWER
4	DV564	INSULATION—FRONT PANEL LOWER
5	DV565	INSULATION— FRONT PANEL LOWER
6	DV566	SIDE PANEL
7	DV567	AIR DROP
8	DV570	OUTER CASING BOTTOM
9	DV571	CONTROL COMPARTMENT DIVIDER
10	DV573	OUTER CASING TOP
11	R618	MOTOR MOUNT (FOUR REQUIRED)
12	DV574	MOTOR MOUNTING BAR
13	R619	MOTOR
*14	R987	FAN BLADE
*15	DV759	FAN HOUSING
16	R1995	TRANSFORMER
17	R690F	CORD
18	DV579	COMBUSTION CHAMBER
19	M96	GASKET—FLUE OUTLET
20	DV765	GASKET—COMBUSTION CHAMBER (TWO REQUIRED)
21	DV764	GASKET—COMBUSTION CHAMBER (TWO REQUIRED)
22	DV973	BURNER DOOR (LP)
22	DV622	BURNER DOOR (NAT.)
23	DV824	BURNER FRONT
24	DV826	BURNER REAR
25	P112	MANIFOLD UNION ASS'Y
26	DV687	MANIFOLD AND PLATE ASS'Y
27	M148	GASKET - MANIFOLD
28	P8853	BURNER ORIFICE (LP)
29	P8841	BURNER ORIFICE (NAT)
30	DV779	GASKET BURNER DOOR
31 A	M155	GASKET - OBSERVATION HOLE
31 B	DV781	OBSERVATION HOLE COVER W/MICA
31 C	DV064	PLATE FOR OBSERVATION HOLE COVER

DV-60-1SPP, SPP


PARTS LIST

Index No.	Part Number	Description
32 A	R622N	PILOT - NATURAL
32 B	R622L	PILOT - LP
33	DV698	PILOT TUBING W/FERRELLS
34	M147	GASKET—TUBING SEAL
35	DV775	SEAL BRACKET
36	R854	PIEZO IGNITOR
37	R685	THERMOCOUPLE
38	R2148	VALVE NAT.
39	R5655	VALVE LP
40	652019	MAGNET (NO LONGER AVAILABLE)
41	922036	OPERATOR (NO LONGER AVAILABLE)
42	652112	REGULATOR NATURAL (NO LONGER AVAILABLE)
43	652212	REGULATOR LP (NO LONGER AVAILABLE)
44	DV598	SWITCH COMPARTMENT
45	R630	LIMIT SWITCH
46	R1941	FAN SWITCH
47	R1034	HI-LO FAN CONTROL
48	DV613	INNER SHIELD—RIGHT
49	DV614	INNER SHIELD—LEFT
50	DV600	VENT KIT
51	DV131	OUTSIDE WALL PLATE
52	DV548	AIR INLET TUBE
53	DV524	FLUE OUTLET TUBE
54	DV725	VENT CAP
55	R6389	WALL THERMOSTAT 24 VOLT
56	R734	LIGHTER ROD (NS)
57	R1196	FAN AND LIMIT WIRE
58	DV832	SWITCH COMPARTMENT COVER (NS)

CONVERSION KIT

TO LP	TO NATURAL
682217	682124

* WHEN ORDERING FAN OR HOUSING FOR REPLACEMENT ON UNITS MANUFACTURED BEFORE 9-1-85 THEY MUST BE ORDERED AS A SET.



DV-60-1SPP, SPP

PARTS LIST

Index No.	Part Number	Description
1	DV559	FRONT PANEL UPPER
2	DV560	INSULATION—FRONT PANEL UPPER
3	DV562	FRONT PANEL LOWER
4	DV564	INSULATION—FRONT PANEL LOWER
5	DV565	INSULATION— FRONT PANEL LOWER
6	DV566	SIDE PANEL
7	DV567	AIR DROP
8	DV570	OUTER CASING BOTTOM
9	DV571	CONTROL COMPARTMENT DIVIDER
10	DV573	OUTER CASING TOP
11	R618	MOTOR MOUNT (FOUR REQUIRED)
12	DV574	MOTOR MOUNTING BAR
13	R619	MOTOR
*14	R987	FAN BLADE
*15	DV759	FAN HOUSING
16	R621	TRANSFORMER
17	R690F	CORD
18	DV579	COMBUSTION CHAMBER
19	M96	GASKET—FLUE OUTLET
20	DV765	GASKET—COMBUSTION CHAMBER (TWO REQUIRED)
21	DV764	GASKET—COMBUSTION CHAMBER (TWO REQUIRED)
22	DV972	BURNER DOOR (LP)
22	DV847	BURNER DOOR (NAT)
23	DV824	BURNER FRONT
24	DV826	BURNER REAR
25	P112	MANIFOLD UNION ASS'Y
26	DV687	MANIFOLD AND PLATE ASS'Y
27	M148	GASKET - MANIFOLD
†28	P8853	BURNER ORIFICE (LP)
†29	P88-41	BURNER ORIFICE (NAT)
30	DV779	GASKET BURNER DOOR
31	DV781	OBSERVATION HOLE COVER W/MICA
32 A	R714N	PILOT NAT.
32 B	R714L	PILOT LP

DV-60-1IP, CIP

PARTS LIST

Index No.	Part Number	Description
33	DV698	PILOT TUBING W/FERRELLS
34	M147	GASKET—TUBING SEAL
35	DV691	SEAL BRACKET
36	R1617	SPARK WIRE
37	R1616	MODULE—INTERMITTENT PILOT
38	R2149	VALVE NAT.
39	R2147	VALVE LP
41	922036	OPERATOR (NO LONGER AVAILABLE)
42	652112	REGULATOR NAT. (NO LONGER AVAILABLE)
43	652212	REGULATOR LP (NO LONGER AVAILABLE)
44	DV598	SWITCH COMPARTMENT
45	R630	LIMIT SWITCH
46	R1941	FAN SWITCH
47	R1034	HI-LO FAN CONTROL
48	DV613	INNER SHIELD—RIGHT
49	DV614	INNER SHIELD—LEFT
50	DV600	VENT KIT
51	DV131	OUTSIDE WALL PLATE
52	DV548	AIR INLET TUBE
53	DV524	FLUE OUTLET TUBE
54	DV725	VENT CAP
55	R6389	WALL THERMOSTAT 24 VOLT
56	R721	WIRE HARNESS - MODULE
57	R1196D	WIRE HARNESS - FAN & LIMIT

CONVERSION KIT


TO LP	TO NATURAL
682221	682151

* WHEN ORDERING FAN OR HOUSING FOR REPLACEMENT ON UNITS MANUFACTURED BEFORE 9-1-85 THEY MUST BE ORDERED AS A SET.

† FOR DV60-CIP

LP ORIFICE PART NO. 742259

NAT. ORIFICE PART NO. 742157



DV-60-1IP, CIP

PARTS LIST

Index No.	Part Number	Description
1	DV559	FRONT PANEL UPPER
2	DV560	INSULATION—FRONT PANEL UPPER
3	DV562	FRONT PANEL LOWER
4	DV564	INSULATION—FRONT PANEL LOWER
5	DV565	INSULATION— FRONT PANEL LOWER
6	DV566	SIDE PANEL
7	DV567	AIR DROP
8	DV570	OUTER CASING BOTTOM
9	DV571	CONTROL COMPARTMENT DIVIDER
10	DV573	OUTER CASING TOP
11	R618	MOTOR MOUNT (FOUR REQUIRED)
12	DV574	MOTOR MOUNTING BAR
13	R619	MOTOR
14	R987	FAN BLADE
15	DV759	FAN HOUSING
16	R1995	TRANSFORMER (NS)
17	R690F	CORD (NS)
18	DV579	COMBUSTION CHAMBER
19	M96	GASKET—FLUE OUTLET
20	DV765	GASKET—COMBUSTION CHAMBER (TWO REQUIRED)
21	DV764	GASKET—COMBUSTION CHAMBER (TWO REQUIRED)
22	DV973	BURNER DOOR (LP)
22	DV622	BURNER DOOR (NAT)
23	DV824	BURNER FRONT
24	DV826	BURNER REAR
25	P112	MANIFOLD UNION ASS'Y
26	DV687	MANIFOLD AND PLATE ASS'Y
27	M148	GASKET - MANIFOLD
28	P8853	BURNER ORIFICE (LP)
29	P8841	BURNER ORIFICE (NAT)
30	DV779	GASKET BURNER DOOR
31 A	M155	GASKET - OBSERVATION HOLE
31 B	DV781	OBSERVATION HOLE COVER W/MICA
31 C	DV064	PLATE FOR OBSERVATION HOLE COVER
32 A	R622N	PILOT NATURAL

PARTS LIST

Index No.	Part Number	Description
32 B	R622L	PILOT LP
33	DV808	PILOT TUBING W/FERRELLS
34	M147	GASKET—TUBING SEAL
35	DV775	SEAL BRACKET
36	R854	PIEZO IGNITOR
37	R685	THERMOCOUPLE
38	R2148	VALVE NAT.
39	R5655	VALVE LP
*40	652019	MAGNET (NO LONGER AVAILABLE)
*41	922036	OPERATOR (NO LONGER AVAILABLE)
*42	652112	REGULATOR NAT. (NO LONGER AVAILABLE)
*43	652212	REGULATOR LP (NO LONGER AVAILABLE)
44	DV598	SWITCH COMPARTMENT
45	R630	LIMIT SWITCH
46	R1941	FAN SWITCH
47	R1034	HI-LO FAN CONTROL
48	DV613	INNER SHIELD—RIGHT
49	DV614	INNER SHIELD—LEFT
50	DV600	VENT KIT
51	DV131	OUTSIDE MOUNTING PLATE
52	DV548	AIR INLET TUBE
53	DV524	FLUE OUTLET TUBE
54	DV725	VENT CAP
55	R6389	WALL THERMOSTAT 24 VOLT
56	R734	LIGHTER ROD (NS)
57	R1196D	WIRE HARNESS - FAN & LIMIT
58	DV777	SWITCH COMPARTMENT COVER (NS)

CONVERSION KIT

TO LP	TO NATURAL	MODEL NUMBER
682217	682124	DV60-2SPP
682270	682161	DV60-3SPP

*NOT NEEDED ON 3SPP

DV-60-2SPP, 3SPP

PARTS LIST


Index No.	Part Number	Description
1	DV559	FRONT PANEL UPPER
2	DV560	INSULATION — FRONT PANEL UPPER
3	DV562	FRONT PANEL LOWER
4	DV564	INSULATION — FRONT PANEL LOWER
5	DV565	INSULATION — FRONT PANEL LOWER
6	DV566	SIDE PANEL
7	DV567	AIR DROP
8	DV570	OUTER CASING BOTTOM
9	DV571	CONTROL COMPARTMENT DIVIDER
10	DV573	OUTER CASING TOP
11	R618	MOTOR MOUNT (FOUR REQUIRED)
12	DV574	MOTOR MOUNTING BAR
13	R619	MOTOR
14	R987	FAN BLADE
15	DV759	FAN HOUSING
16	R1995	TRANSFORMER (NS)
17	R690F	CORD (NS)
18	DV579	COMBUSTION CHAMBER ASS'Y
19	M96	GASKET — FLUE OUTLET
20	DV765	GASKET — COMBUSTION CHAMBER (TWO REQUIRED)
21	DV764	GASKET — COMBUSTIONCHAMBER (TWO REQUIRED)
22	DV972	BURNER DOOR (LP)
22	DV847	BURNER DOOR (NAT)
23	DV824	BURNER FRONT
24	DV826	BURNER REAR
25	P112	MANIFOLD UNION ASS'Y
26	DV687	MANIFOLD AND PLATE ASS'Y
27	M148	GASKET - MANIFOLD
28	P8853	BURNER ORIFICE (LP)
29	P8841	BURNER ORIFICE (NAT)
30	DV779	GASKET BURNER DOOR 36"
31	DV781	OBSERVATION HOLE COVER ASS'Y W/MICA
32 A	762113	PILOT NAT.
32 B	R714L	PILOT LP

**DV-60-2IP, 2CIP
DV-60-3IP, 3CIP**

PARTS LIST

Index No.	Part Number	Description
33 A	DV698	PILOT TUBING W/FERRELLS (DV60 2IP, CIP)
33 B	DV808	PILOT TUBING W/FERRELLS (DV60 3IP, CIP)
34	M147	GASKET — TUBING SEAL
35	DV691	SEAL BRACKET
36	R1617	SPARK WIRE
37	R1616	MODULE — INTERMITTENT PILOT
38	R2149	VALVE NAT.
39	R2147	VALVE LP
*41	922036	OPERATOR (NO LONGER AVAILABLE)
*42	652112	REGULATOR NAT. (NO LONGER AVAILABLE)
*43	652212	REGULATOR LP (NO LONGER AVAILABLE)
44	DV598	SWITCH COMPARTMENT
45	R630	LIMIT SWITCH
46	R1941	FAN SWITCH
47	R1034	HI-LO FAN CONTROL
48	DV613	INNER SHIELD — RIGHT
49	DV614	INNER SHIELD — LEFT
50	DV600	VENT KIT
51	DV131	OUTSIDE MOUNTING PLATE
52	DV548	AIR INLET TUBE
53	DV524	FLUE OUTLET TUBE
54	DV725	VENT CAP
55	R6389	WALL THERMOSTAT 24 VOLT
56	R721	WIRE HARNESS - MODULE
57	R1196D	WIRE HARNESS - FAN & LIMIT
58	DV777	SWITCH COMPARTMENT COVER (NS)
CONVERSION KIT		
	TO LP	TO NATURAL MODEL UNIT
	682221	682151 DV60-2IP, 2CIP
	682269	682160 DV60-2IP, 3CIP
	DV1185	DV1186 DV60-2CIP, DV60-3CIP

* NOT NEEDED ON 3CIP, IP



DV-60-2IP, 2CIP
DV-60-3IP, 3CIP

PARTS LIST

Index No.	Part Number	Description
1	11762	OUTER CASING TOP (BEIGE)
2	R618	MOTOR MOUNT (FOUR REQUIRED)
3	11764	MOTOR MOUNTING BAR (TWO REQUIRED)(BEIGE)
4	M147	GASKET (TWO REQUIRED)
5	R619G	MOTOR
6	11787	FAN BLADE
7	11786	FAN HOUSING
8	DV559	UPPER FRONT PANEL
9	11759	SIDE PANEL(BEIGE)
10	DV613	RIGHT INNER SHIELD
11	DV725	VENT CAP
12	DV131	OUTSIDE MOUNTING PLATE
13	DV548	AIR INLET TUBE
14	DV524	FLUE OUTLET TUBE
15	DV600	VENT KIT COMPLETE (NOS. 11, 12, 13, 14)
16	DV567	AIR DROP
17	M96	GASKET FOR FLUE OUTLET FLANGE
18	DV579-C	COMBUSTION CHAMBER
19	R1536	BUSHING
20	11765	SWITCH COMPARTMENT ASSEMBLY
21	R630	LIMIT CONTROL
22	R1941	FAN CONTROL
23	DV832	SWITCH COMPARTMENT COVER
24	DV562	LOWER FRONT PANEL
25	DV826	REAR BURNER
26	R685	THERMOCOUPLE
27	R622L	PILOT WITH ORIFICE LP GAS (INCLUDES ELECTRODE & WIRE)
27	R622N	PILOT WITH ORIFICE NATURAL GAS
28	DV808	PILOT TUBING
29	DV824	FRONT BURNER
30	P8842	MAIN BURNER ORIFICE NATURAL GAS (TWO REQUIRED)
30	P8853	MAIN BURNER ORIFICE LP GAS (TWO REQUIRED)
31	DV687	MANIFOLD AND PLATE ASSEMBLY
32	M148	MANIFOLD GASKET
33	M155	GASKET FOR OBSERVATION HOLE COVER
34	DV781	OBSERVATION HOLE COVER W/MICA
35	DV064	COVER PLATE FOR OBSERVATION HOLE
36	DV775	SEAL BRACKET
37	M147	GASKET TUBING SEAL
38	DV622	BURNER DOOR NATURAL GAS
38	DV973	BURNER DOOR LP GAS


DV-55-SPP

PARTS LIST

Index No.	Part Number	Description
39	DV779	GASKET FOR BURNER DOOR
40	P112	MANIFOLD UNION
41	R5566	GAS VALVE VR8200C LP GAS
41	R2148	GAS VALVE VR8200C NATURAL GAS
42	UH810	TRANSFORMER MOUNTING BRACKET
43	R1995	TRANSFORMER
44	UH451	JUNCTION BOX COVER
45	11760	OUTER CASING BOTTOM
46	R1515	BUSHING
47	R854	PIEZO W/NUT (PRE "P" SERIAL NUMBER)
47	R2708	PIEZO PUSH-IN TYPE ("P" SERIAL NUMBER & LATER)
48	DV571	CONTROL COMPARTMENT DIVIDER
49	DV671	MANIFOLD SUPPORT
50	DV765	GASKET FOR CHAMBER AIR INLET (TOP & BOTTOM) (TWO REQUIRED)
51	DV764	GASKET FOR CHAMBER AIR INLET (SIDES) (TWO REQUIRED)
52	R690F	CORD SET
53	R1404	BUSHING
54	DV614	LEFT INNER SHIELD
55	11759	SIDE PANEL
NS	R1196-D	FAN AND LIMIT WIRE
NS	R633	24 VOLT WALL THERMOSTAT
NS	R734	LIGHTER ROD
NS	R3470	PILOT ORIFICE LP GAS
NS	R3469	PILOT ORIFICE NATURAL GAS
NS	DV855	PUTTY PAC

CONVERSION KIT

TO LP	TO NATURAL
682270	682161



DV-55-SPP

PARTS LIST

Index No.	Part Number	Description
1	11762	OUTER CASING TOP (BEIGE)
2	R618	MOTOR MOUNT (FOUR REQUIRED)
3	11764	MOTOR MOUNTING BAR (TWO REQUIRED)
4	M147	GASKET (TWO REQUIRED)
5	R619	MOTOR
6	11787	FAN BLADE
7	11766	FAN HOUSING
8	DV559	UPPER FRONT PANEL
9	11759	SIDE PANEL
10	DV613	RIGHT INNER SHIELD
11	DV725	VENT CAP
12	DV131	OUTSIDE MOUNTING PLATE
13	DV548	AIR INLET TUBE
14	DV524	FLUE OUTLET TUBE
15	DV600	VENT KIT COMPLETE (NOS. 11, 12, 13, 14)
16	DV567	AIR DROP WELDED ASSEMBLY
17	M96	GASKET FOR FLUE OUTLET FLANGE
18	DV579-C	COMBUSTION CHAMBER
19	R1536	BUSHING
20	11765	SWITCH COMPARTMENT ASSEMBLY
21	R630	LIMIT CONTROL
22	R1941	FAN CONTROL
23	DV832	SWITCH COMPARTMENT COVER
24	DV562	LOWER FRONT PANEL
25	DV826	REAR BURNER
26	R1617	SPARK PLUG WIRE
27	R714L	PILOT WITH ORIFICE LP GAS
27	R714	PILOT WITH ORIFICE NATURAL GAS
28	DV808	PILOT TUBING
29	DV825	FRONT BURNER
30	P8842	MAIN BURNER ORIFICE NATURAL GAS (TWO REQUIRED)
30	P8853	MAIN BURNER ORIFICE LP GAS (TWO REQUIRED)
31	DV687	MANIFOLD AND PLATE ASSEMBLY
32	M148	MANIFOLD GASKET
33	M155	GASKET FOR OBSERVATION HOLE COVER
34	DV781	OBSERVATION HOLE COVER W/MICA


DV-55-IP

PARTS LIST

Index No.	Part Number	Description
35	DV064	COVER PLATE FOR OBSERVATION HOLE
36	DV691	SEAL BRACKET
37	M147	GASKET TUBING SEAL
38	DV847	BURNER DOOR NATURAL GAS
38	DV972	BURNER DOOR LP GAS
39	DV779	GASKET FOR BURNER DOOR
40	P112	MANIFOLD UNION
41	R2147	GAS VALVE VR8204C LP GAS
41	R2149	GAS VALVE VR8204C NATURAL GAS
42	UH810	TRANSFORMER MOUNTING BRACKET
43	R1995	TRANSFORMER
44	UH451	JUNCTION BOX COVER
45	11760	OUTER CASING BOTTOM
46	R1515	BUSHING
47	R690F	CORD SET
48	DV571	CONTROL COMPARTMENT DIVIDER
49	DV671	MANIFOLD SUPPORT
50	DV765	GASKET FOR CHAMBER AIR INLET (TOP & BOTTOM) (TWO REQUIRED)
51	DV764	GASKET FOR CHAMBER AIR INLET (SIDES) (TWO REQUIRED)
52	DV692	CONTROL MODULE MOUNTING BRACKET
53	R721	WIRE HARNESS FOR CONTROL MODULE
54	R1616	CONTROL MODULE
55	R1404	BUSHING
56	DV614	LEFT INNER SHIELD
57	11759	SIDE PANEL
NS	R1196-D	FAN AND LIMIT WIRE
NS	R6389	24 VOLT WALL THERMOSTAT
NS	R734	LIGHTER ROD
NS	R358	PILOT ORIFICE LP
NS	R7429	PILOT ORIFICE NATURAL

CONVERSION KIT

TO LP	TO NATURAL
682269	682160



DV-55-IP

PARTS LIST

Index No.	Part Number	Description
1	11762	OUTER CASING TOP
2	R618	MOTOR MOUNT - 4 REQUIRED
3	11764	MOTOR MOUNTING BAR - 2 REQUIRED
4	M147	GASKET - 2 REQUIRED
5	R619-G	MOTOR
6	11787	FAN BLADE
7	11766	FAN HOUSING
8	DV558	FRONT PANEL UPPER
9	11759	SIDE PANEL - 2 REQUIRED
10	DV613	INNER SHIELD - RIGHT
11	13057	OUTLET TUBE - INNER ASSEMBLY (INCLUDES 12 & 13)
12	M177	GASKET - OUTLET COLLAR
13	13104	OUTLET TUBE - INNER WELDED ASSEMBLY
14	13062	INNER TUBE - INNER ASSEMBLY (INCLUDES 15 & 16)
15	M178	GASKET - INLET COLLAR
16	13106	INLET TUBE - INNER WELDED ASSEMBLY
17	13064	INLET TUBE - OUTER ASSEMBLY
18	13059	OUTLET TUBE - OUTER ASSEMBLY
19	13053	VENT CAP ASSEMBLY WELDED
20	13110	AIR DROP WELDED ASSEMBLY
21	M176	GASKET - FLUE OUTLET FLANGE
22	13113	COMBUSTION CHAMBER WELDED ASSEMBLY
23	R1536	BUSHING
24	11765	SWITCH COMPARTMENT
25	R630	LIMIT CONTROL
26	R1941	FAN CONTROL
27	DV832	SWITCH COMPARTMENT COVER
28	DV562	FRONT PANEL - LOWER
29	DV826	REAR BURNER ASSEMBLY
30	R685	THERMOCOUPLE
31	R622L	PILOT WITH ORIFICE - LPG GAS
31	R622N	PILOT WITH ORIFICE - NAT GAS
32	DV808	PILOT TUBING
33	DV824	FRONT BURNER ASSEMBLY
34	P8841	ORIFICE - NAT GAS - 2 REQUIRED


DV-55T-1

PARTS LIST

Index No.	Part Number	Description
34	P8853	ORIFICE - LPG GAS - 2 REQUIRED
35	DV687	MANIFOLD
36	M148	GASKET - MANIFOLD
37	M155	GASKET-OBSERVATION HOLE COVER
38	DV781	LIGHTING HOLE COVER ASSEMBLY
39	DV064	COVER PLATE-OBSERVATION HOLE
40	DV775	SEAL BRACKET
41	M147	GASKET - TUBING SEAL
42	DV622	BURNER DOOR - NAT GAS
42	DV973	BURNER DOOR - LPG GAS
43	DV779	GASKET - BURNER DOOR
44	P112	MANIFOLD UNION
45	R5655	GAS VALVE - LPG GAS
45	R2148	GAS VALVE - NAT GAS
46	UH810	TRANSFORMER MOUNTING BRACKET
47	R1995	TRANSFORMER
48	UH451	JUNCTION BOX COVER
49	11760	OUTER CASING BOTTOM
50	R1515	BUSHING
51	R2708	PIEZO IGNITOR
52	DV571	CONTROL COMPARTMENT DIVIDER
53	DV671	MANIFOLD SUPPORT
54	DV765	GASKET - CHAMBER AIR INLET (TOP & BOTTOM) - 2 REQUIRED
55	DV764	GASKET - CHAMBER AIR INLET (SIDES) - 2 REQUIRED
56	R690-B	CORD SET
57	R1404	BUSHING
58	DV614	INNER SHIELD - LEFT
NS	R1196D	WIRE HARNESS
NS	R6389	THERMOSTAT
NS	R734	LIGHTER ROD

CONVERSION KIT

TO LP	TO NATURAL
682270	682161



DV-55T-1

PARTS LIST

Index No.	Part Number	Description
1	11762	OUTER CASING TOP
2	R618	MOTOR MOUNT - 4 REQUIRED
3	11764	MOTOR MOUNTING BAR - 2 REQUIRED
4	M147	GASKET - 2 REQUIRED
5	R619G	MOTOR
6	11787	FAN BLADE
7	11766	FAN HOUSING
8	DV558	FRONT PANEL UPPER
9	11759	SIDE PANEL
10	DV613	INNER SHIELD - RIGHT
11	13057	OUTLET TUBE - INNER ASSEMBLY (INCLUDES 12 & 13)
12	M177	GASKET - OUTLET COLLAR
13	13104	OUTLET TUBE - INNER WELDED ASSEMBLY
14	13062	INLET TUBE - INNER ASSEMBLY (INCLUDES 15 & 16)
15	M178	GASKET - INLET COLLAR
16	13106	INLET TUBE - INNER WELDED ASSEMBLY
17	13064	INLET TUBE - OUTER ASSEMBLY
18	13059	OUTLET TUBE - OUTER ASSEMBLY
19	13053	VENT CAP WELDED ASSEMBLY
20	13110	AIR DROP WELDED ASSEMBLY
21	M176	GASKET - FLUE OUTLET FLANGE
22	13113	COMBUSTION CHAMBER WELDED ASSEMBLY
23	R1536	BUSHING
24	11765	SWITCH COMPARTMENT
25	R630	LIMIT CONTROL
26	R1941	FAN CONTROL
27	DV832	SWITCH COMPARTMENT COVER
28	DV562	FRONT PANEL - LOWER
29	DV826	REAR BURNER ASSEMBLY
30	R1617	SPARK PLUG WIRE
31	R714-L	PILOT WITH ORIFICE - LPG GAS
31	R714-N	PILOT WITH ORIFICE - NAT GAS
32	DV808	PILOT TUBING
33	DV825	FRONT BURNER ASSEMBLY
34	P8841	ORIFICE - NAT GAS - 2 REQUIRED
34	P8853	ORIFICE - LPG GAS - 2 REQUIRED
35	DV687	MANIFOLD


DV-55IPT-1

PARTS LIST

Index No.	Part Number	Description
36	M148	GASKET - MANIFOLD
37	M155	GASKET-OBSERVATION HOLE COVER
38	DV781	LIGHTING HOLE COVER ASSEMBLY
39	DV064	COVER PLATE-OBSERVATION HOLE
40	DV691	SEAL BRACKET
41	M147	GASKET - TUBING SEAL
42	DV847	BURNER DOOR - NAT GAS
42	DV972	BURNER DOOR - LPG GAS
43	DV779	GASKET - BURNER DOOR
44	P112	MANIFOLD UNION
45	R2147	GAS VALVE - LPG GAS
45	R2149	GAS VALVE - NAT GAS
46	UH810	TRANSFORMER MOUNTING BRACKET
47	R1995	TRANSFORMER
48	UH451	JUNCTION BOX COVER
49	11760	OUTER CASING BOTTOM
50	R1515	BUSHING
51	R690-B	CORD SET
52	DV571	CONTROL COMPARTMENT DIVIDER
53	DV671	MANIFOLD SUPPORT
54	DV765	GASKET - CHAMBER AIR INLET (TOP & BOTTOM) - 2 REQUIRED
55	DV764	GASKET - CHAMBER AIR INLET (SIDES) - 2 REQUIRED
56	DV692	MODULE MOUNTING BRACKET
57	R721	WIRE HARNESS - CONTROL MODULE
58	R1616	CONTROL MODULE
59	R1404	BUSHING
60	DV614	INNER SHIELD - LEFT
61	11759	SIDE PANEL
NS	R1196-D	WIRE HARNESS
NS	R6389	THERMOSTAT
NS	R734	LIGHTER ROD

CONVERSION KIT

TO LP	TO NATURAL
682269	682160



DV-55IPT-1

PARTS LIST

Index No.	Part Number	Description
1	DV1213	TOP PLATE
2	R3165	DOOR CLIP (2 REQUIRED)
3	DV1204	CASING SIDE - RIGHT
4	DV1202	CASING BACK
5	DV1205	CASING SIDE - LEFT
6	DV1249	AIR DROP
7	DV1230	TURBULATOR (3 REQUIRED)
8	DV1233	OUTLET BOX REAR
9	DV1224	OUTLET BOX COVER
10	R3161	FAN BLADE
11	R3166	FAN MOTOR
12	DV1246	MOTOR MOUNTING BRACKET
13	R1536	BUSHING (4 REQUIRED)
14	R1499	RUBBER GROMMET (4 REQUIRED)
15	R1454	BRASS BUSHING (4 REQUIRED)
16	R3164	DOOR CLIP (2 REQUIRED)
17	DV1251	INNER SHIELD - RIGHT (INCLUDES NO. 22)
18	R6176	FAN CONTROL SWITCH
19	R3175	LIMIT SWITCH
20	DV1255	INNER SHIELD FRONT
21	DV1253	INNER SHIELD COVER PLATE (2 REQUIRED)
22	DV1252	INNER SHIELD -LEFT (INCLUDES NO. 22)
23	DV1257	EXCHANGER ASSEMBLY
24	R3162	FILTER
25	R3163	FILTER RETAINER
26	R3232	PILOT - NAT (IP ONLY)
26	R3233	PILOT - LPG (IP ONLY)
27	P8852	ORIFICE - NAT (3 REQUIRED)
27	P8860	ORIFICE - LPG (3 REQUIRED)
28	DV1236	MANIFOLD
29	DV1259	FRONT PANEL
30	P112	MANIFOLD UNION
31	R1109	BUSHING 3/8 X 1/2
32	R3170	GAS VALVE - NAT (IP ONLY)
32	R3171	GAS VALVE - LPG (IP ONLY)
32	R2148	GAS VALVE - NAT (SPP ONLY)
32	R5655	GAS VALVE - LPG (SPP ONLY)
33	R2708	PIEZO IGNITOR (SPP ONLY)
34	DV781	OBSERVATION HOLE COVER WITH MICA
35	M155	GASKET - OBS HOLE
36	FF160	PIEZO BRACKET (SPP ONLY)
37	DV1240	BURNER COMPARTMENT FRONT


PARTS LIST

Index No.	Part Number	Description
38	DV1265	BURNER COMPARTMENT BODY
39	M147	GASKET - TUBE SEAL
40	DV775	SEAL BRACKET (SPP ONLY)
40	DV691	SEAL BRACKET (IP ONLY)
41	M148	MANIFOLD GASKET
42	DV1235	PILOT BRACKET (IP ONLY)
43	R3031	BURNER (3 REQUIRED)
44	DV1239	BURNER BRACKET
45	UH810	TRANSFORMER MOUNTING BRACKET (SPP ONLY)
45	UH452	TRANSFORMER MOUNTING BRACKET (IP ONLY)
46	R1995	TRANSFORMER (SPP ONLY)
46	R998	TRANSFORMER (IP ONLY)
47	UH451	JUNCTION BOX COVER
48	DV572	JUNCTION BOX
49	R1410	BUSHING
50	R690F	CORD SET
51	R1515	BUSHING
52	DV1215	BOTTOM PLATE
53	R3034	PILOT - NAT (SPP ONLY)
53	R3035	PILOT - LPG (SPP ONLY)
54	GWT021	PILOT BRACKET (SPP ONLY)
55	R3180	ELECTRODE AND WIRE (SPP ONLY)
56	R2256	THERMOCOUPLE -18" (SPP ONLY)
57	R6389	WALL THERMOSTAT - 24 VOLT
58	DV1273	VENT KIT COMPLETE
59	DV1355	FLUE OUTLET TUBE
60	DV1354	AIR INLET TUBE
61	DV131	OUTSIDE MOUNTING PLATE
62	DV769	VENT CAP
NS	DV1261	PILOT TUBING
NS	R1081	PILOT ORIFICE - NAT (SPP ONLY)
NS	R1089	PILOT ORIFICE - LPG (SPP ONLY)
NS	R1233	PILOT ORIFICE - NAT (IP ONLY)
NS	R3265	PILOT ORIFICE - LPG (IP ONLY)
NS	R3172	WIRE HARNESS (SPP ONLY)
NS	R3173	WIRE HARNESS (IP ONLY)
NS	R3236	WIRE (IP ONLY)

Conversion Kit

DVC-35-1SPP
DVC-35-1IP

Model Number	To LP	To Natural
DVC-35-1SPP	DV1344	DV1346
DVC-35-1IP	DV1348	DV1350



**DVC-35-1SPP
DVC-35-1IP**

PARTS LIST

Index No.	Part Number	Description
1	DV1213	TOP PLATE
2	R3165	DOOR CLIP (2 REQUIRED)
3	DV1204	CASING SIDE - RIGHT
4	DV1202	CASING BACK
5	DV1205	CASING SIDE - LEFT
6	DV1249	AIR DROP
7	DV1230	TURBULATOR (3 REQUIRED)
8	13213	OUTLET BOX REAR
9	13217	OUTLET BOX COVER
10	R3161	FAN BLADE
11	R3166	FAN MOTOR
12	DV1246	MOTOR MOUNTING BRACKET
13	R1536	BUSHING (4 REQUIRED)
14	R1499	RUBBER GROMMET (4 REQUIRED)
15	R1454	BRASS BUSHING (4 REQUIRED)
16	R3164	DOOR CLIP (2 REQUIRED)
17	DV1251	INNER SHIELD - RIGHT (INCLUDES NO. 22)
18	R6176	FAN CONTROL SWITCH
19	R3175	LIMIT SWITCH
20	DV1255	INNER SHIELD FRONT
21	DV1253	INNER SHIELD COVER PLATE (2 REQUIRED)
22	DV1252	INNER SHIELD -LEFT (INCLUDES NO. 22)
23	13211	EXCHANGER ASSEMBLY
24	R3162	FILTER
25	R3163	FILTER RETAINER
26	R3232	PILOT - NAT (IP ONLY)
26	R3233	PILOT - LPG (IP ONLY)
27	P8852	ORIFICE - NAT (3 REQUIRED)
27	P8860	ORIFICE - LPG (3 REQUIRED)
28	DV1236	MANIFOLD
29	DV1259	FRONT PANEL
30	P112	MANIFOLD UNION
31	R1109	BUSHING
32	R3170	GAS VALVE - NAT (IP ONLY)
32	R3171	GAS VALVE - LPG (IP ONLY)
32	R2148	GAS VALVE - NAT (SPP ONLY)
32	R5655	GAS VALVE - LPG (SPP ONLY)
33	R2708	PIEZO IGNITOR (SPP ONLY)
34	DV781	OBSERVATION HOLE COVER ASSEMBLY
35	M155	GASKET
36	FF160	PIEZO BRACKET (SPP ONLY)
37	DV1240	BURNER COMPARTMENT FRONT
38	DV1265	BURNER COMPARTMENT BODY
39	M156	GASKET


DVC-35T-1
DVC-35IPT-1

PARTS LIST

Index No.	Part Number	Description
40	DV775	SEAL BRACKET (SPP ONLY)
40	DV691	SEAL BRACKET (IP ONLY)
41	M148	MANIFOLD GASKET
42	DV1235	PILOT BRACKET (IP ONLY)
43	R3031	BURNER (3 REQUIRED)
44	DV1239	BURNER BRACKET
45	UH810	TRANSFORMER MOUNTING BRACKET (SPP ONLY)
45	UH452	TRANSFORMER MOUNTING BRACKET (IP ONLY)
46	R1995	TRANSFORMER (SPP ONLY)
46	R998	TRANSFORMER (IP ONLY)
47	UH451	JUNCTION BOX COVER
48	DV572	JUNCTION BOX
49	R1410	BUSHING
50	R690	CORD SET
51	R1515	BUSHING
52	DV1215	BOTTOM PLATE
53	R3034	PILOT - NAT (SPP ONLY)
53	R3035	PILOT - LPG (SPP ONLY)
54	GWTO21	PILOT BRACKET (SPP ONLY)
55	R3180	ELECTRODE AND WIRE ASSEMBLY (SPP ONLY)
56	R2256	THERMOCOUPLE -18" (SPP ONLY)
57	R6389	WALL THERMOSTAT - 24 VOLT
58	13057	OUTLET TUBE - INNER ASSEMBLY (INCLUDES 59 & 60)
59	M177	GASKET - OUTER COLLAR
60	13104	OUTLET TUBE - INNER WELDED ASSEMBLY
61	13062	INLET TUBE - INNER ASSEMBLY (INCLUDES 62 & 63)
62	M178	GASKET - INLET COLLAR
63	13106	INLET TUBE - INNER WELDED ASSEMBLY
64	13064	INLET TUBE - OUTER ASSEMBLY
65	13059	OUTLET TUBE - OUTER ASSEMBLY
66	13053	VENT CAP WELDED ASSEMBLY
NS	DV1261	PILOT TUBING
NS	R1081	PILOT ORIFICE - NAT (SPP ONLY)
NS	R1089	PILOT ORIFICE - LPG (SPP ONLY)
NS	R1233	PILOT ORIFICE - NAT (IP ONLY)
NS	R3265	PILOT ORIFICE - LPG (IP ONLY)
NS	R3172	WIRE HARNESS (SPP ONLY)
NS	R3173	WIRE HARNESS (IP ONLY)
NS	R3236	WIRE (IP ONLY)
NS	DV1264	HARDWARE PACKAGE

Conversion Kit

Model Number	To LP	To Natural
DVC-35T-1	DV1344	DV1346
DVC-35IPT-1	DV1348	DV1350



**DVC-35T-1
DVC-35IPT-1**