

vario programming

carb
entry controller

~~enter pass~~

EC =

① connect

entry controller

② read

③ open EB 602-3

Russ ok

use up/down to enter

5 3 4 5

use → to move right

press of

④ data is read

access displaying properly

BSM = intercom